



Single Way Charger Model 4497L



The charger is shipped with the battery locating rail in the standard battery position.

To change to the thick battery position:

1. Remove the battery locating rail by pinching inward both sides while pulling from the charger pocket.
2. Turn the battery locating rail around so the back faces the front.
3. Re-insert into the charger pocket.

Battery Locating Rail Adapter

The battery locating rail is a removeable part which constitutes an adapter to accommodate standard and thick batteries.



**You can change the direction of the spacer.
Then, your charger can support different kinds of CP200
batteries (Flat back and Round back).**